

OUTER VENTILATION HOOD WITH FROST PROTECTION





PURPOSE

The outer ventilation hood is designed to prevent ingress of water and foreign objects into the ventilation equipment from outside and to protect the ventilation duct and equipment inside it from frost.



PHYSICAL, MENTAL, OR SENSORY CAPACITIES, OR THOSE WITHOUT THE APPROPRIATE TRAINING. THE UNIT MUST BE INSTALLED AND CONNECTED ONLY BY PROPERLY QUALIFIED PERSONNEL AFTER THE APPROPRIATE BRIEFING.

THE UNIT SHOULD NOT BE OPERATED BY CHILDREN OR PERSONS WITH REDUCED

THE CHOICE OF UNIT INSTALLATION LOCATION MUST PREVENT UNAUTHORISED ACCESS BY UNATTENDED CHILDREN.

OVERALL DIMENSIONS



DESIGN AND OPERATING PRINCIPLE

When the outdoor temperature drops below -10 °C (-14 °F), the thermostat switches on the heating cable, thus protecting the hood, ventilation duct and the products in it against frost.





the outer wall surface.

suitable tool.

marking.



4. Lay the ventilation hood power cord from the outer side of the air duct.

Fix the back part of the ventilation hood on the wall using the supplied screws 4 mm (³/16")x40 mm (1⁹/16").

Connect the power cord in the room according to the wiring diagram.





CONNECTION TO POWER MAINS

Outer ventilation hood is equipped with frost protection. The power consumption of the hood depends on the temperature conditions and is no more than 60 W (230 V/50 Hz). Sustaining current is 0.26 A.

TERMINAL DESIGNATIONS ON THE WIRING DIAGRAM:

L - phase

N - 0

QF- automatic circuit breaker



CAUTION! The hood is approved for use at temperatures from -35 °C (-22 °F) to +50 °C(+122 °F) . The manufacturer cannot guarantee correct operation of the hood under conditions other than those specified.

MANUFACTURER'S WARRANTY

The warranty period is 12 months from the date of purchase. The Supplier is particularly not liable for damages arising during transportation, incorrect handling and unapproved modifications or repair work.

Outer ventilation hood with frost protection is recognized as serviceable		
Quality Inspector's Stamp	Manufacture Date	
Seller Name of Retail Company, Stamp of the Shop Purchase Date		







BLAUBERG







www.blaubergventilatoren.de B113-10EN-01